

CIRCLE SYSTEMS, INC.

479 West Lincoln
P. O. Box 1228
Hinckley, IL 60520
Ph.: 815-286-3271
Fax: 815-286-3352
customerservice@circlesafe.com



TECHNICAL BULLETIN #227

Type 2000 Magnetic Stripe Cards

The Type 2000 Magnetic Stripe Card (MSC) is a tool for instantly evaluating the performance of magnetic particle inspection (MPI) materials. The magnetic stripe of the Type 2000 MSC contains two encoded tracks. The upper track is labeled from 0 to 10 (X) when read from left to right. The lower track is a mirror image of the upper track and is labeled from 10 (X) to 0 when read from left to right.

Each track is magnetically encoded with a series of gradients that decrease in intensity in the direction of 0 to X. A more sensitive MPI powder will display a greater number of observable gradients or indications than a less sensitive material. The Type 2000 MSC can be used to quantitatively evaluate the performance of MPI powders by displaying the number of indications that can be observed after the powder has been applied to the stripe. Magnetic Stripe Cards are recognized as a tool for evaluation of magnetic particle inspection materials in ASTM E-709-08 "Standard Guide for Magnetic Particle Examination", Paragraph 20.6.8 and Appendix X4; as well as in ASTM E-1444-05 "Standard Practice for Magnetic Particle Testing", Appendix X7.3.

How to use the Type 2000 MSC:

The card can be exposed to fluid suspensions by pouring or spraying the bath over the card, or, by dipping the card in the bath, and allowing excess fluid to flow off. Observations can be made immediately. The fluid may be allowed to evaporate off, allowing permanent recording, as described below. For dry powders blow or sprinkle the powder over the card. Remove the excess powder by gently blowing over the stripe.

Using the scales printed next to the stripe observe the number of visible indications. A reading may be recorded as the number of observable indications on either or both of the magnetic tracks. Both tracks should display close to the same number of indications, as long as the MPI material is evenly applied.

Permanent documentation is easy. Firmly press the transparent tape over the dried indications and transfer the tape to Form 93-MSC-1. Records can be used to document bath conditions, make on-site bath standards and other purposes.

Precautions:

When not in use the Type 2000 MSC should be kept away from excessive heat and cold, and strong magnetic fields. For optimum performance, the Type 2000 MSC should be used at room temperature. The stripe material has a coercivity of 2,750 Oersteds. In the unlikely event that the stripe

